

Digital Indicator for industries D2-501B

Digital Indicator
for DC Voltage & DC Current input type

General features

- Peak, hold, data protection(Key lock), auto zero :
Front jey or external signal terminal operation
- Sampling speed (max. 15 times)
- Auto calinration, offset function
- Filtering : 10Hz, 100Hz, 1kHz, W/B (User selectable)



Performance specs.

Digital Indicator D2-501B

Display

- Range : -19999 to 99999 (5 digit)
- Decimal point : selectable position
- 5-digit segment FND
- Sampling seppd : 15 times / sec
- Output update : 500Hz
- Display Bit : 14.5 Bit (1/18,000)
- CPU Bit : 32 Bit

Sensor input

- DC 4...20mA or 0...10V (2-wire, 3-wire)
- Excitation voltage : DC 24V (80mA)
- Accuracy : $\pm 0.02\%$ of reading
- impedance : 100M Ohm


Dual limit relays

Relay mode : Hysteresis, Normal, Range function

Relay capacity : AC 250V - 0.25A

AC125V - 0.5A, DC 24V - 1A

Ordering information



DAHO Tronic Limited
 Tel: 02-865-7001 Fax: 02-865-7109
 mail: info@daho.co.kr


STX W-Tower 209
 Gyeongin-ro 53 Gil 90 Guro-gu
 Seoul 08215 Korea

www.daho.co.kr


Special function

No.	Function	Setting
1	Auto zero	Press 2nd key(▲) while pressing 4th key(ENT)
2	Peak	Press 2nd key(▲) to turn on, 3rd key(▶) to turn off
3	Key lock	While holding 2nd key(▲), press 3rd key(▶) at the same time, "Loc" is displayed When you run it again, "UnLoc" is displayed and off.
4	Reset	Turn on the power while pressing 4th key(ENT), "Init" is displayed. Press 2nd key(▲) to change to "yes", and press 3rd key(▶) and 4th key(ENT)s at the same time. When flasing "Yes", it is initialized when the key is released.
5	Menu Back	Press 3rd key(▶) while holding 1st key(PRG), the screen moves to the previous mode.
6	Zero clear	"CLR-0" is displayed by pressing the 3rd key(▶) while pressing 4th key(ENT). At this time, press 2nd key(▲) while pressing, Zero clear.


Drawing



Front View



Side View



Panel Cutting Size

Wiring

